

ASSEMBLY INSTRUCTIONS

Mayotte Large Offset Floor Lamp Item # ARN 1013

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Carefully remove all parts from the carton.
2. Insert light bulb into socket.
3. Remove plastic cover (C) from electrical plug (A).
4. Plug lamp into wall outlet.

ADJUSTMENT INSTRUCTION

1. Loosen adjustment key (A).
2. Adjust lamp shade to desired position.
3. Tighten adjustment key (A).

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

