

## Assembly Instruction Sheet #IS-GRT8604C For Style GRT8604C

Please go to www.guoizel.com for product cleaning tips. Go to the Care + Maintenance selection. Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (4)A19 Medium Base bulbs 100W Maximum, Medium Base Vintage Bulbs are recommended, bulbs not included. Estimated Assembly Time: 20-30 minutes Preparation: Identify and inspectal parts before beginning installation. Check package content list and diagrams below to ensure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts. Fixture can only be mounted in the direction indicated on page 2. 🛆 Warnings and Cautions Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Package Contents screwing the mounting screws or alternate short mounting screws in or out of the crossbar until the correct length is achieved. Once the Glass backplate and Fixture Body (D) is secure, remove the mounting ball С Shade Crossbar and Fixture Body (D) and proceed to Step 3. x 4 A Assembly x 1 Mounting Screw or Alternate Short Mounting Screw Alternate В Mounting screw D Fixture Body x 2 D x 1 Mounting Ball Hex Nut and Backplate Lock Washer Figure 2 STEP 1 - Installing the Crossbar Assembly A. Pass the supply wires through the Crossbar Assembly (A). Attach **STEP 3 - Wire Connections** the Crossbar Assembly (A) to the Outlet Box with the head of the Green Ground Screw facing you. Secure the Crossbar Assembly (A) A. Wrap bare or green ground wire around green ground screw on the with Outlet Box Screws (not included). Tighten until snug. crossbar, no less than 2 inches from the end of the wire. Tighten the Note: Use the Alternate Shorter Mounting Screw (B) if your green ground screw. installation requires a shorter mounting screw. B. Use standard wire connectors (not included) to make all wire connections. Twist connectors until wires are tightly joined together. Outlet Box Screws Wrap each connection with approved electrical tape and carefully (not included) stuff all the connected wires into the Outlet Box. Outlet Box Supply Wires White wire White wire Mounting Screw from outlet box with Ground Wire from fixture or Alternate Short Black wire Black wire from Mounting Screw from fixture outlet box (or Red) Figure 1 Bare, or Green Ground wire Ground wire STEP 2 - Test Fit the Backplate to the Crossbar Assembly from Fixture from outlet box A. Remove the mounting balls from the Crossbar Assembly (A). Place the backplate and Fixture Body (D) onto the Crossbar Assembly (A) Green Ground Screw and secure with mounting balls. Note: The backplate and Fixture on the Crossbar Body (D) should be snug against the wall and held tight with the mounting balls. If it is not, adjust the length of the mounting screw or Figure 3 alternate short mounting screw on the Crossbar Assembly (A) by unscrewing the preassembled hex nut and lock washer and then Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-800-645-3184 or visit us on-line at www.quoizel.com © 2018 Quoizel Inc. Released Date: 2018-03-02

